



# **FaxCore 2007 Administrator Manual**



Version 5.2

## Administrator's Guide



# Table of Contents

---

Introduction to FaxCore 2007 .....	1
FaxCore Customer Support & Services .....	1
Understanding FaxCore 2007 .....	2
FaxCore 2007 .....	3
Initial Configurations & Steps .....	4
Accessing FaxCore 2007 Admin Panel for the first time .....	4
Configuring the Fax Agent and Outbound Routes .....	6
Configuring FaxCore 2007 to Send and Receive Transmissions .....	6
Configuring the Fax Agent .....	8
Configuring Fax Port to Send and Receive Transmissions .....	9
Configuring Dialing Rules .....	11
Configuring Port Grouping for Outbound Transmissions .....	12
Setting Up Outbound Routing Rules .....	13
Setting up Domain Information .....	16
Set up Company Information .....	16
Setting up Users .....	18
Manually create users .....	18
Synchronize Users from Microsoft Active Directory/Lotus Notes .....	21
Directory Sync and Directory Connection .....	21
Search Filter Settings .....	22
Processing Rules .....	22
Processing Rules – User Identification .....	23
Processing Rules – New User Handling .....	23
Processing Rules – Existing User Handling .....	23
Processing Rules – Inbound Route Handling .....	24
Processing Rules – Deleted User/Domain Handling .....	24
Processing Rules – Exchange Integration .....	25
Import users from CSV .....	25
Import Specification .....	26
Default Settings .....	26
Import Users from CSV Schema .....	26
Routing Inbound Faxes to Users .....	27
Set up Inbound Routing Rules .....	27
Set up Notifications for Users .....	30
Notification Permissions .....	30
Select Default Email Attachment Format .....	31
Domain Settings .....	32
Setup Email Relay Settings .....	32
Configuring Microsoft SMTP for FaxCore Email Gateway .....	33
Create Exchange Connector - Route Emails to FaxCore Gateway .....	36
Configuring Exchange to send faxes to FaxCore .....	36
Additional Global Settings .....	38
Printer Settings (Global Settings) .....	38
Creating and Editing Network Printer .....	40
Email Integration (Global Settings) .....	42

Server Settings (Global Settings).....	44
Network Identification .....	44
Additional Domain Settings.....	45
Transmission and Retry Settings (Domain Settings) .....	45
User Permissions (Domain Settings) .....	47
Send Permissions .....	47
Received Permissions .....	48
Document Permissions.....	49
Domain Setting – Domain Settings.....	49
Email Delivery / Notification Identification .....	49
Message Setting .....	49
Support Request Setting.....	50
Notification Delivery Templates.....	50
User Permissions.....	52
Fax Settings.....	56
Tracking Configuration.....	59
Tracking Dictionary .....	62
Domain Management.....	64
Domain Info .....	65
Users .....	66
Groups.....	68
Address Book.....	70
Delivery Templates .....	72
Network Setting .....	75
Message Queue Monitor .....	75
Message Schedule .....	76
Utilities.....	76
Import Contacts.....	76
Import Specification.....	76
Default Settings.....	77
Import Contacts from CSV Schema .....	77
Help and Support .....	78
Product Information .....	79
Error Logging.....	79
Token Reference .....	79
Configuration Tokens .....	80
Message Token .....	81
User Token.....	84
Table of Figures .....	85



## Introduction to FaxCore 2007

With the new release of the award winning FaxCore 2007, FaxCore takes the lead in today's faxing technology by providing a comprehensive and centralized fax solution to automate fax communications and easily fax-enable business processes and other third-party applications. FaxCore 2007 is built ground up on Microsoft .NET 2.0 platform and Microsoft SQL 2005 database to enable enterprise to leverage and integrate with applications based on Microsoft's latest technology.

As a strategic partner of Dialogic, the industry standard in intelligent fax hardware and Fax over IP drivers and Microsoft Certified Gold Partner, FaxCore provides end users with a stable and solid solution which ensures seamless integration with today's telephony equipments and Microsoft applications.

## FaxCore Customer Support & Services

FaxCore customers are encouraged to purchase a FaxCore Support Contract which provides them with unlimited telephone, email and web based product support. FaxCore Partners can also provide on-site support and training when needed. FaxCore Support Contract holders are entitled to all FaxCore product service packs and upgrades at no additional charge.

**Web Support:** [www.faxcore.com](http://www.faxcore.com): The site contains technical information as well as a list of frequently asked questions.

*U.S. & Europe*

**Email Support:** Email support is available at [support@faxcore.com](mailto:support@faxcore.com)

**Phone Support:** FaxCore support technicians can be reached at +1 (720) 870 2900

*Asia Pacific*

**Email Support:** Email support is available at [support@faxcore.com.my](mailto:support@faxcore.com.my)

**Phone Support:** FaxCore support technicians can be reached at +60 (3) 3324 3226



## Understanding FaxCore 2007

FaxCore 2007 fax server comprises of the following modules and components:

### **FaxCore IIS web component (FaxCore Web Client & Admin Panel)**

FaxCore web client allow users to view, send, forward, retrieve, search and print faxes from any compatible Web browser. Also include admin panel for administrator to manage the fax server.

### **FaxCore Render Agent (Document Rendering Engine)**

This is the document conversion engine that renders native documents to faxable format (TIFF) and submits documents to the fax board.

### **FaxCore FaxAgent (Fax board & FoIP Drivers)**

This service/component handles fax requests from and to FaxCore fax server and act as the agent between FaxCore fax services and the fax board.

### **FaxCore SMTP listener (Email to Fax integration)**

This service/component handles and parse email messages sent from any SMTP enabled email servers to be sent as faxes through FaxCore.

### **FaxCore File Gateways (Embedded Codes & Control File Integration)**

Enable backend applications such as ERP, CRM & AS/400 to drop faxes into network folders/FTP with embedded fax information which is monitored by the file gateway service.

### **FaxCore database (Microsoft SQL 2005 engine)**

Stores transactional records and information of all incoming/outgoing faxes, users, domain & system information.

### **FaxCore Web Services/SOAP SDK**

Allow 3<sup>rd</sup> party application to integrate FaxCore functionalities through a set of comprehensive APIs.

FaxCore 2007 offers the following versions of the software:

### **FaxCore 2007 Small Medium Enterprise (SME) / Integration Server (FIS) Edition**

- Includes a single server license with two (2) fax lines
- Support up to fifty (50) user license and four (4) fax channels
- FaxCore Web Client
- FaxCore IP Fax Printer Driver
- FaxCore Web Services SDK
- Microsoft Exchange & SMTP Email Integration
- Microsoft SQL 2005 Express Edition

### **FaxCore 2007 Standard Edition**

- Includes single server license with two (2) fax line licenses.
- Support unlimited users and up to eight (8) fax channels
- FaxCore Web Client



- FaxCore IP Fax Printer Driver.
- FaxCore Web Services SDK
- Microsoft Exchange & SMTP Email Integration.
- Microsoft SQL 2005 Express Edition

### **FaxCore 2007 Enterprise Edition**

- Includes single server license with two (2) fax line licenses.
- Support unlimited users and fax channels
- FaxCore Web Client
- FaxCore IP Fax Printer Driver.
- FaxCore Web Services SDK
- Microsoft Exchange & SMTP Email Integration.
- FaxCore File Gateways/Embedded Codes
- Microsoft SQL 2005 Standard Embedded Edition

### **FaxCore 2007 Add-On Modules**

*(Applicable to all editions)*

- Barcode Module
- Lotus Notes Gateway & Client Forms
- RoboFAX module
- FaxCore MFP Connector (Sharp, Fuji Xerox, Xerox, eCopy)
- FaxCore File Gateways

## **FaxCore 2007**

For detailed instructions and information to install the software, refer to the FaxCore 2007 Installation Guide.





## Initial Configurations & Steps

Before you can begin sending and receiving faxes with your FaxCore 2007 server, you will need to login as an administrator to setup a few initial configurations to ensure the fax server is configured to meet your enterprise's requirements.


To configure FaxCore fax server you will need to:

1. Configuring the Fax Agent & Outbound Routes
  - Setup driver information (Area Code, Country Code)
  - Enable Fax Ports to send and receive faxes
  - Configure Dialing Rules
  - Setup Outbound Routing rules
2. Setting Up Domain Information
  - Setup company information
  - Setup regional & language settings
3. Setup Users
  - Adding/Create users manually or sync from Microsoft Active Directory/Lotus Notes
4. Routing inbound faxes to users
  - Setup routing information for inbound faxes to users
  - Setup notifications for users
  - Select default email attachment format
5. Setup email relay settings

## Accessing FaxCore 2007 Admin Panel for the first time

### **Note: FaxCore URL (Address)**

Obtain the FaxCore address from your system administrator.

1. To login to the Admin Panel, open up your web browser use the following link below and hit [Enter]. <http://servername/admin/> The Login to FaxCore Web Client screen will display.
2. Enter your **Login username**, which is **admin**.
3. Enter your **Password**. Initially it is **password**.
4. Click . Upon successful login, the primary window appears.







## Configuring the Fax Agent and Outbound Routes

### Configuring FaxCore 2007 to Send and Receive Transmissions

To configure FaxCore to send and receive transmissions (faxes and emails) complete the following steps.


1. Click  on the Admin Panel.
2. Click .

The FaxAgent Management screen displays.

#### **Note: Dialogic Brooktrout Intelligent Fax Boards**

FaxCore is designed to work with Dialogic Brooktrout Intelligent Fax Boards. The Boston Driver Installation program installs drivers for Dialogic Brooktrout TR1034, SR140 and TruFax fax boards.

All servers hosting fax boards should have a full-qualified DNS name on the dropdown menu to make sure proper reporting occurs.



Fax Agent: FAXCORE X Delete Refresh Help

**FaxAgent Management**

Configuration Ports Dialing Rules Agent Monitor Ports Group

Save

**Agent Information**

FaxAgent Server Name FAXCORE (100005)

FaxAgent Server IP 192.168.8.90

FaxAgent Label

**Driver Information**

Fax Driver Brooktrout

Service Path C:\WINDOWS\TEMP\FaxCore.Server

Configuration Path C:\Program Files\Brooktrout\config

Country Code 1

Area Code

Current Status Running

Total Fax Ports

**Figure 3 – Fax Agent Management**


### **Note: To Delete a Fax Agent**

The Fax Agent dropdown menu shows the names of local and remote Fax Agents actually hosted.

Select the name of the unnecessary Fax Agent and click  to the right it.

## Configuring the Fax Agent

- Fax Agent Server Name – Displays the name of the selected Fax Agent server
- Fax Agent Server IP – Displays the IP address of the selected Fax Agent server
- Fax Agent Label – Description label of the selected Fax Agent server
- Fax Driver – The name of the Fax Driver currently in use
- Service Path – Default path; in this example is the computer's local hard drive
- Configuration Path – Default configuration file and its location
- Country Code – Country code where the Fax Agent server resides
- Area Code – Area code where the Fax Agent server resides
- Current Status – Current operational status of the Fax Agent service
- Total Fax Port – Total available number of licensed ports



Fax Agent: FAXCORE [X Delete] [Refresh]

### FaxAgent Management

**Configuration** | Ports | Dialing Rules | Agent Monitor | Ports Group

[Save]

#### Agent Information

FaxAgent Server Name: TESTER (100005)  
 FaxAgent Server IP: 10.0.0.116  
 FaxAgent Label:

#### Driver Information

Fax Driver: Brooktrout  
 Service Path: C:\WINDOWS\TEMP\FaxCore.Server  
 Configuration Path: C:\Program Files\Brooktrout\config  
 Country Code: 1  
 Area Code: 303  
 Current Status: Stopped  
 Total Fax Ports:

*Confirm the settings in the Driver Information section match your telephony settings.*

#### Fax Configuration

Fax Number Pooling: ☐ Pool outgoing faxes to the same destination to a predefined port.


**Figure 4 – Fax Agent Management - Configuration**

Click the **Ports** tab on the Fax Agent Management screen. This section allows management of the available fax ports for the selected Fax Agent.

- Fax Agent:  ✕ Delete ↺ Refresh 🔗 Help

### FaxAgent Management

Configuration
**Ports**
Dialing Rules
Agent Monitor
Ports Group

 Save

FaxAgent Utilization:  %

	Module	Port	Enabled	Send Enabled	Receive Enabl...	Tone Detect E...	Status
<a href="#">Edit</a>	M2,0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Idle
<a href="#">Edit</a>	M2,1	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Idle

Click  to the left of the module to modify each port/channel configuration.

- Answers Ring – Numbers of rings before answer
- Dial Timeout – Total time in seconds to drop an idle call
- Local CSID – Local CSID for the particular port
- Tone Detect Digits – Enable to activate DTMF tone detect
- Header Style - Fax header to be stamped on the top of all pages of the transmission

Edit Port Configuration

Port 0 configuration

Answer Ring

3

Dial Timeout (sec)

60

Local CSID

FAXCORE

Tone Detect Digits

4

Tone Wait Timeout (sec)

0

Greeting Type

Tone

Greeting WAV File

Header Style

Default

Saved to all.

Apply All

Apply




**Figure 6 – Fax Agent Management - Ports - Edit Port Configuration**

Click and drag the title bar of this screen to reposition it, if the screen is not visible in its entirety.

### Figure 7Ports - Edit Port Configuration - Greeting Type


Header Style

### Figure 8Ports - Edit Port Configuration - Header Style

Click  or  Saved to all.  
Click  to close the Edit Port Configuration screen.





To add a custom dialing rule, enter the dial string and replace with the number you want to replace and click “Add” 

To disable any dialing rule, just uncheck the box and click “Save”. 


## Configuring Port Grouping for Outbound Transmissions

FaxCore 2007 allows the administrator to group available send ports for outbound faxes. This feature is useful when there are certain department / domain users that require a dedicated number of ports to send faxes.

For example, your FaxCore server has 4 ports available for sending and you want to dedicate 3 of the 4 available ports for users in Domain A. You can do so by grouping Port 0, 1 & 2 into a port group and define an outbound rule for Domain A to use the Port Group to send faxes.

This new feature provides the administrator with a simple manageable method to assign ports to users and domain.

To create a new Port Group, click the “**Ports Group**” tab in the Fax Agent Management screen and enter the following information and select the ports to group.



Edit	Remove	Group Name	Group Description	Total Count
		Human Resource Dept	GrpA	3
		Accounts Dept	Accounts Dept	3
		IT Dept	IT Dept	1
		Sales Dept	Sales Dept	6

Figure 11 – Fax Agent Management -Port Groups



- Group Name – Group to use the outbound rule.
- Group Descriptions – Group description.
- Unassigned Ports – Available port to use for outbound.

- Group Ports – Ports that is selected to use for outbound.
- Edit – Edit outbound rule.
- Remove – Remove outbound rule.
- Total Count – Total number of ports that is using for the particular group.

## Setting Up Outbound Routing Rules

To begin sending faxes from FaxCore 2007, you will need to create at least one outbound routing rule. The outbound routes defines which fax server or fax agent to use to send outbound faxes and can be configured for each domain, individual users and based on dial string (digits). In addition, you can further group ports on each fax agent to dedicate those ports to be used by certain domain(s), user(s) or dial string (digits).

Outbound routes based on dial string are particularly useful for Least Cost Routing purposes.

Click the  link then followed by the  link to display the outbound routing management page.



New

Refresh

Help

Outbound Routing

Number of items to display 15

Edit	Active	Priority	Route String	Server Type	Server Name
	 Yes	100	[Routing Digit] = 'x'	Fax Agent	FAXCORE (100005)

**Figure 12 – Global Setting -Outbound Routing Rules**

Figure 13 – Global Setting -Outbound Routing Rule

To setup an outbound route, browse to “**Global Setting**” and click “**Outbound Routing**”. Click the “**New**” button and a new Outbound Route window will show.

To begin, choose the appropriate route string depending on whether you want to configure the new outbound route for the entire **domain** or for a particular **user**. After selecting either Domain or User, click “**Preview**” and you will see the outbound route token string automatically insert below in the text box.

Next choose “**Fax Agent**” as Server Type and Server ID will be the board agent server name. “**Assign Method**” can be based on individual ports or port groups created on the Fax Agent page earlier. Click “**Save**” to save the setting for the new outbound route.

Below is the basic example of a typical outbound route for most enterprise:

- Conditions: Domain = System
- Route Type: Fax Agent
- Assign Method: Port or Port Group

- Port No: \* (or Port Group depending on the Assignment method)


If Assign method is Port Group, the following field, Port No becomes Group.

Group

Accounts Dept
Human Resource Dept
Accounts Dept
IT Dept
Sales Dept

- Activate Route: Yes
- Priority: 100

The above settings will use all (\*) available ports on the Fax Agent to send faxes for the users in residing in the “System” domain. If you create users in a different domain name, use that domain instead.




### **Alert: Outbound Routes for each Domain**

**Administrators must create outbound routes for each domain on the FaxCore 2007 server.**


## Setting up Domain Information

Domain setting can only be modified by a user that is an administrator for the domain or parent domain. Domain setting are available from the “**Domain Setting**” web page.



The Domain info page displays general and summary information about the domain and allows the general properties of the domain to be modified. Users within the same domain will inherit the information configure the domain info page. To modify domain properties, make the necessary changes and click the “**Save**” button to apply the changes.


## Set up Company Information



Company Settings	
Company Name	FaxCore, Inc.
Address Street 1	Suite 207
Address Street 2	19590 E. Main Street
Address Street 3	
Address City	Parker
Address State/Region	CO
Address Postal	80138
Address Country	United States

**Figure 14 - Domain Settings - Company Information**

- Configure Domain – Domain details to be displayed or configured.
- Company Name – Company Name for the domain.
- Address Street 1 – 1st line for the company address.
- Address Street 2 – 2nd line for the company address.
- Address Street 3 – 3rd line for the company address.
- Address City – Company address city.
- Address State/Region – Company address state or region.
- Address Postal – Company address postal code.
- Address Country – company address country.




**Regional & Language Settings**

Regional Culture	English(United States)	▼
Date Format	YYYY-MM-DD	▼
Time Format	02:10:15 p	▼

**Figure 15 - Domain Settings - Regional and Language Settings**

- Regional Culture – Language / culture setting. Controls formatting of dates and numbers.
- Date Format – Format for displaying date portion of date time fields overrides the regional culture setting.
- Time Format – Format for displaying time portion of date time fields overrides the regional culture setting.
- Time Zone – The GMT time zone offset.



**Attachment Settings**

Email Attachment Format	pdf	▼
-------------------------	-----	---

**Figure 16 - Domain Settings - Attachment Settings**


## Setting up Users

There are 3 methods to create users in FaxCore 2007:


- Manually creating users locally.
- Importing users from a CSV type document.
- Synchronize users from an LDAP compliant server of either Microsoft Active Directory or Lotus Domino

### Manually create users



To create users manually, browse to “Domain

Management”  **Domain Management** tab and select

Users.



**Figure 17 - Domain Management - Users**

To create a new user, click on the  **New** button from the user list above. The User create dialog will be display. On the “New User” page enter the required user information and click the “Save”  **Save** any changes to create the new user. You will see a notification that confirms the **New user is created.**



User Management - Windows Internet Explorer provided by Yahoo!

http://co.faxcore.com/admin/DmnMgmt/UserForm.aspx?domain=0

Save Help

**Select Domain**

Configure Domain: SYSTEM

**User Info**

User Name: JohnJosephSmith

User Password: ••••

User Role: SUPER USER

Authentication Type: Internal

Is Active: Yes

Display Name: John Joseph Smith

First Name: John

Middle Name: Joseph

Last Name: Smith

Prefer Address Type: EMAIL

**Addresses** Add Address

Edit	Remo...	NOR	NOS	Prima...	Type	Address
No address(es) added						

Done Internet 100%

**Figure 18 - Domain Management - User Information**

- Configure Domain – Domain the user belong to.
- User Name – Username (Used for logon)
- User Password – Password.
- User Role – Indicates the privilege level for the user
  - ✓ System Admin
  - ✓ Domain Admin
  - ✓ Super User
  - ✓ Normal User
- Authentication – Indicates if the user should be set to authenticate with an external directory or internal directory for logon.
- Is Active – Indicate if the user to be set as active or non active account
- Display Name – Users Display Name.

- First Name – Users First Name.
- Middle Name – Users Middle Name.
- Last Name – Users Last Name.
- Preferred Address Type – Users preferred address notification type.

Click **Add Address**.

**Figure 19 - Domain Management - User's Address**

- Address Type – Defines which address should be used as the primary delivery address for the user.
- Address – Defines the address.
- Format – Default format to send as attachment to the address.
- Include address in receive notification – Check to receive notification for the user.
- Include address in send notification – Check to receive send notification for the user.

Click **Add New** to append the new notification address to the user profile.

Click **Close** when you no longer need to add additional addresses.

The new user's email address shows below his other information as follows.

Edit	Remo...	NOR	NOS	Prima...	Type	Address
		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Email	johnjosephsmith@go-write.com


**Figure 20 - Domain Management - User's Addresses**

Click **Save** to apply the changes.

## Synchronize Users from Microsoft Active Directory/Lotus Notes

Directory Synchronization functionality allows FaxCore to synchronize users with 3rd party directory server such as Active Directory or Lotus Domino. This allows administrators to quickly and easily add and maintain FaxCore users and permissions via their existing directories and databases.

To synchronize users from Active Directory, browse to the “Domain Settings” tab




and select “Directory Sync”

Synchronizing with an external directory is a one-way read-only process. During synchronization, FaxCore will read the external directory and update the FaxCore database by adding, modifying, or deleting users. The external directory source is never modified in anyway.

Directory Synchronization is set at the Domain level. Options chosen may have an effect on the sub-domains, since sub-domains can inherit options of the parent domain.

FaxCore allows control of which FaxCore users are synchronized on a user by user basis. In other words, a FaxCore Domain may contain both users that are set to be synchronized with the external directory, and also users that will not be synchronized. This ensures that native FaxCore user accounts can exist without being affected by directory synchronization. Current FaxCore users can be included / excluded from synchronization from the Domain Users page by selecting the users and executing the appropriate action (enable directory sync, disable directory sync) from the action drop list.

### Directory Sync and Directory Connection




The image shows two stacked configuration screens. The top screen, titled 'Directory Sync', has a 'Configure Domain' dropdown menu set to 'SYSTEM' and a 'Last Sync' field. The bottom screen, titled 'Directory Connection', has several fields: 'Directory Provider' (dropdown set to 'MS Active Directory (LDAP)'), 'Logon Server' (text field with 'steamboat'), 'Logon Username' (text field with 'administrator'), 'Logon Password' (password field with masked characters), and 'Authentication Type' (dropdown set to 'Secure').

**Figure 21 - Domain Settings - Directory Sync – Directory Connection**

- Configure Domain – Define the domain which users are to be synchronized to.
- Last Sync – Last synchronized date and time
- Directory Provider – The type of directory that is being synchronized.

- Logon Server – The DNS resolvable hostname of the server where the directory resides.
- Logon Username – the username to use to logon to the directory.
- Logon Password – the password to use to logon to the directory.
- Logon Password Confirm – confirm the password to use to logon to the directory.
- Authentication Type –


## Search Filter Settings



**Figure 22 - Domain Settings – Directory Sync - Search Filter Settings**

- Domain – Limit the directory users read based on specific domain.
- Organization Units – Limit the directory users read based on specific organizational unit. Organization Units can be specified with simple name or by full qualified LDAP path.
- Security Groups – Limits the directory users based on specific security groups.
- Custom Filter – additional custom LDAP style filters to apply when reading the directory.
- Include Sub domain - Limits the directory users based on specific security domain.
- Properties to Read – Additional Active Directory properties to read.
- Max Users to Read – Total numbers of users to synchronize.

## Processing Rules



**Figure 23 - Domain Settings – Directory Sync - Processing Rules - General**

- Synchronize Mode – Specifies how inbound fax route should be created for users

- ✓ Add only – Add new users only
- ✓ Update only – Update Users only
- ✓ Add and Update – Add and Update users
- Synchronize Type – Specifies method to synchronize.
  - ✓ User only – Only synchronize user
  - ✓ User and Domain – Synchronize User and Domain
- Authentication Mode – Choose authentication type.
- Enable Auto Sync – Choose yes or no for Faxcore to automatic synchronization.
- Intervals – Set date and time for the next synchronize.
- Auto Sync Next Day – Choose the particular date to auto sync.

## Processing Rules – User Identification




Figure 24 - Domain Settings – Directory Sync - Processing Rules – User ID

## Processing Rules – New User Handling




Figure 25 - Domain Settings – Directory Sync - Processing Rules – New User Handling

- New User Password – Default users password after sync
- Prefer Address Type – Choose preferred address.
- Authentication Mode – Default users to either external or internal authentication mode
- Inbound Route Handling – **DO NOT MODIFY ROUTES (DO NOTHING)**

## Processing Rules – Existing User Handling




Figure 26 - Domain Settings – Directory Sync - Processing Rules – Existing User Handling





## Processing Rules – Exchange Integration




Exchanger Server	<input type="text"/>
Exchange Version	Exchange 2003 and below
Form Based Authentication Enabled	No


Figure 29 - Domain Settings – Directory Sync - Processing Rules - General

## Import users from CSV

To import users from a CSV file, browse to “**Utilities**” tab




and select “**Import Users**”.



The User Import utility allows administrator to import users from an external data file into FaxCore domains. The User Import utility has the following feature:

- Allow the system administrator to import users into any domain.
- Allow the specification of common default value for fields not present in the external data file.
- Support any line delimited flat file format.



FaxCore 2007 - Admin Panel

**Import Specification**

FaxCore Domain	SYSTEM
Import File	<input type="text"/> Browse...
Header Format	FaxCore Default Import Header
File Type	Csv
Has header	Yes
Format	CSV Delimited

**Default Settings**

User Password	<input type="text"/>
User Role	SYSTEM ADMIN
File Attachment Format	pdf
Prefer Address Type	EMAIL
Include Address In Receive Notification	Yes
Include Address In Send Notification	Yes
Authentication	Internal
Route Field	<input type="text"/>
Route Priority	99

Figure 30 - Utilities - Import Users



## Import Specification

- FaxCore Domain – Domain the user belongs to.
- Import Files – Identifies the custom control file to use for the import.  
Click [Browse...](#).
- Header Format– Display the control file that has header
- Format- Format of the data in the data file. The location of the data fields in the data file is specified using a control file.
- Table Name - Name for the table

## Default Settings

- User Password – User default password
- User Role – User privilege Level
- File Attachment Format – Default file attachment format for addresses
- Prefer Address Type – Indicates if the primary (preferred) address type for the contact.
- Authentication – Indicates if the used should be setup to sync with an external directory or just internally.

## Import Users from CSV Schema

The following table shows the list of data fields that appears in the pre-configured control file.

Data Field Name	Description
UserName	FaxCore login username.
DisplayName	User's display name.
FirstName	User's first name.
MiddleName	User's middle name.
LastName	User's last name.
CompanyName	User's company name.
Email	User's email address.
Fax	User's fax number.
Http	User's http address.
Ftp	User's ftp address.

Data Field Name	Description
File	User's file address.
Printer	User's printer.
Mobile	User's mobile number.
FaxRaw	User's raw fax number.
Phone	User's phone number.

## Routing Inbound Faxes to Users

### Set up Inbound Routing Rules


Routing of inbound faxes to users is defined in Inbound Routing rules. When a fax is received, FaxCore search for a matching inbound routing rule to determine where the received fax should be routed to. When one or more properties of the received fax matches the criteria defined on an inbound routing rule and the fax will be routed to the user or group that is defined on the inbound route.

Inbound faxes can be routed based on several properties of the received fax including the following:

- Barcode Data
- Fax Port No
- Routing Digits
- Remote Caller ID
- Remote CSID
- Server Name

To create a new inbound route, browse to “**Global Settings**” tab and select the Inbound Routing link.





- Forward Type – Indicates whether to forward the fax to a user or group.
- Forward Address – User or group to forward the fax.
- Route String – Property to route by
- Activate Route – Indicates if the route is active (will be included in the routing).
- Priority – Priority of the route. Lowest number is higher priority.

Click the  Save button to apply the changes.

## Set up Notifications for Users

For users to receive email notifications, administrators must first enable the permission for users to receive notifications. Proceed to the user permissions page by clicking on the




**Domain Settings**



**User Permissions**

link then followed by the

link.



**Figure 33 - Domain Settings - User Permissions**


### Notification Permissions

- Allow Notify When Message Receive Success – Allows FaxCore to notify the users when receive success.
- Allow Notify When Message Receive Fail - Allows FaxCore to notify the users when receive Fails.
- Allow Notify When Message Send Success – Allows FaxCore to notify the users when send success.
- Allow Notify When Message Send Fail - Allows FaxCore to notify the users when send Fail


Click the **Save** button to apply the changes.

## Select Default Email Attachment Format


To select the default email attachment format of inbound faxes, browse to “Global Settings”

 **Domain Settings**

and select “Server Settings”

 Domain Settings

. Email attachment of fax images can be rendered as either “TIF” or “PDF”




**Figure 34 - Domain Settings – Domain Settings**

## Domain Settings

### Setup Email Relay Settings

Before FaxCore can send out email messages and notifications, you must configure a relay server setting for FaxCore to use to send out emails. The relay server settings should be configured for each domain. The Relay Server Settings can be found in the “**Domain Settings**” tab under the SMTP Relay Settings page.



**Figure 35 - Domain Settings – SMTP Relay Settings**

- Server name – The hostname of the relay server.
- Port – Relay port number, default port is 25
- Default credential On – Credential requirement on or off
- Logon User Name – Email server user authentication
- Logon user Password – Email server Password authentication
- SSL Enable – Define SSL mode


Click the  **Save** button to apply the changes.



## Configuring Microsoft SMTP for FaxCore Email Gateway


FaxCore 2007 utilizes Microsoft SMTP on IIS to allow emails sent to FaxCore Email Gateway to be converted to outbound faxes.

1. To enable this feature, open Microsoft IIS Manager by click on “Start” -> “Program Files” -> “Administrative Tools” -> “Internet Information Services (IIS) Manager”




**Figure 36 - Internet Information Services (IIS) Manager**

2. Select “Default SMTP Virtual Server” and then “Domains”. Right click on the FaxCore server hostname on the right screen and select “Properties”






**Figure 37 - Internet Information Services (IIS) Manager – Access Properties**

3. Change the Drop Directory field value to the FaxCore installation folder  
\\xGateway\smtp\inbox. eg. X:\FaxCore\xgateway\smtp\inbox




### Figure 38 - Internet Information Services (IIS) Manager –Properties

- Click  then  to save the changes.
- Next right click on “Domains” on the Default SMTP Virtual Server node and select “New” -> “Domain”





**Figure 39 - Default SMTP Virtual Server - Domain - New**

6. Select “Alias” for domain Type.




**Figure 40 - New SMTP Domain Wizard Dialog Box**

- Click .
- Enter the domain name to be used to send email to fax messages (eg. fax.companyname.com).



**Figure 41 - New SMTP Domain Wizard Dialog Box**

- Click .
- Configure the Microsoft Exchange Server to forward email messages with the domain name created here to the FaxCore server.

## Create Exchange Connector - Route Emails to FaxCore Gateway

Create an Exchange Connector to route emails to the FaxCore Email Gateway on Microsoft Exchange 2000/2003.

To eliminate IT concerns about installing third-party software on the email server, the Fax Connector is installed within FaxCore and a new **Route** is created on the email server.


The **Route**, created with native Connectors in Exchange, simply forwards messages destined for a FAX address to the Fully Qualified Domain Name (FQDN) of the FaxCore server.

### Configuring Exchange to send faxes to FaxCore


1. Launch the Exchange System Manager.

For *Exchange 2000*, select **Administrative Groups > Routing Groups > Connectors**.  
 For *Exchange 2003*, select **Connectors**.

2. Right-click Connectors and select **New** from the drop down menu.
3. Select **SMTP Connector** from the short-cut menu.




**Figure 42 - MS Exchange System Manager**


4. Configure the Connector
  - a. Provide a **Name** for the new **Connector**.  
**FaxCore** is the recommended name.
  - b. Check “Forward all mail through this connector to the following smart host” and set the smart host to be the Fully Qualified Domain Name of the FaxCore server.
  - c. Add a Local Bridgehead, select the exchange server from the list.  
 Click  and select the server from the list.



### Figure 43 - MS Exchange System Manager - Properties – General



**Figure 44 - MS Exchange System Manager – Other Address Space Properties**

5. Enter **FAX** in the **Type** field.
6. Confirm that **1** in the **Cost** field.
7. Confirm that an asterisk (\*) is in the **Address** field.
8. Click .
9. Test the new Connector by sending an email to the Business Fax address of an MS Outlook Contact.  
You may also enter a one-off address in the **To** field of the mail message with the following syntax, [FAX:RecipientName@faxnumber].


If Outlook is not able to resolve the message type, it means that the new Connector has not been propagated yet. The address type of FAX is usually acknowledged within a few minutes of creating the Connector.

## Additional Global Settings


Global Configuration options are system and advance domain level settings and permissions; they can only be modified by the System Administrator. Select “Server Settings”

### Printer Settings (Global Settings)

FaxCore delivery agents include the ability to send inbound and outbound faxes and documents to any network printer available via TCP/IP. Network Printer definitions provide the FaxCore system administrator the ability to define the name and location of the network printers that they want to give users access to.



**Figure 45 - Global Settings - Printer Settings**

Click the  button to call up the printer management window.



Untitled Page - Windows Internet Explorer provided by Yahoo!

http://co.faxcore.com/admin/GlobalSetting/PrinterSetting.aspx

### Network Printer

Configure Domain	SYSTEM
Printer Label	
Description	
Visibility	Private
Server Name	
Printer Name	
Paper Size	Printer Default
Allow Banner Page	Yes
Horizontal Margin(inch)	
Vertical Margin(inch)	

Banner Page

```

-- FaxCore Network Print Job
--
-- User: $$USER.USERNAME$$
-- Domain: $$USER.DOMAIN_NAME$$
-- Name: $$USER.DISPLAY_NAME$$
-- Date: $$UTIL.DATE_TIME$$

```

Disclaimer: Default banner page used for direct printing. The default banner page can include any user based tokens including:

- \$\$USER.USERNAME\$\$ - The user submitting the print job.
- \$\$USER.DOMAIN\_NAME\$\$ - The FaxCore domain the user belongs to.
- \$\$USER.DISPLAY\_NAME\$\$ - The user display name.
- \$\$UTIL.DATE\_TIME\$\$ - The date and time the print job was submitted.

Done Internet 100%



**Figure 46 - Global Settings - Printer Settings - Network Printer**







- Activate This Network Printer – Indicate if the printer is active.
- Server Name – Windows server printer is defined on or connected to
- Printer Name – Printer name.
- Page Size – Default page size.
- Font Name – Default font name.
- Font Size –Default Font size.
- Font Weight – Default font weight.
- Allow Banner Page – Indicate if the banner page to be printer out
- Horizontal Margin – Horizontal margin in inches.
- Vertical Margin – Vertical margin in inches.
- Prints Duplex – Indicates the duplex mode to print.
- Connect Username – Username that connect to printer.
- Connect Password – Password that connect to printer.
- Connect Domain – Domain that connect to printer
- Banner Page – To banner page defined on the printer definition is used for ad-hoc printing of messages and documents from the FaxCore message viewer. Note: printer based notifications will use the banner page defined in the appropriate delivery template.

## Email Integration (Global Settings)

Click the  **Global Settings** button followed by the  **Email Integration** button.







**Figure 47 - Global Settings - Email Integration**

Click the  **New** button to bring up the email integration form.

**Figure 48 - Global Settings - Email Integration Setting**


The email integration form allows you to define the permissible external domains that the SMTP Listener should accept email traffic from, and how the emails map to FaxCore users and domains for outbound fax creation.

- **External Domain** - The external domain from which faxes through the email gateway are allowed. The wildcard character '\*' can be used for basic pattern matching. When processing an email to fax request, FaxCore compares this value to the domain of the sender account. For example, if FaxCore received an email message from [joesmith@abc.com](mailto:joesmith@abc.com), it would search through the mappings for an entry that matched "acme.com". Note: to define a mapping that allows email traffic from all domains, simply enter a wildcard expression such as '\*.com'.
- **Map to user in domain** - the FaxCore domain that will be used to search for the corresponding Faxcore user that the outbound fax will be created under. Faxcore tries to match the email sender account with a Faxcore user using the following algorithm:
- **Search for user in subdomains** - Indicates if FaxCore should try to match the email sender with users in sub-domains.
- **Allow anonymous** - Indicates if FaxCore should process an email even when it can't find a matching FaxCore user using the above criteria. If enabled, all email that cannot be mapped to a specific FaxCore user will get processed under the user account defined by the faxcore profile to assign to un-mapped users setting. This allows for administrators to allow anonymous email to fax functionality from anyone within their organizations, without having to explicitly create FaxCore user accounts.
- **Profile to assign to anonymous** - User account and profile to which un-mapped email request will get assigned.
- **Active this mapping** - Indicate the mapping is active.


1. For each mapping that you want to add, complete the fields and click on the  (Save) button. The mapping will appear in the table at the main page.
2. To modify a mapping, click on the  (edit) button. Modify the fields and click the  (Save) button.
3. To delete a mapping, click on the  (Remove) button.

## **Server Settings (Global Settings)**

### **Network Identification**


 [Server Settings](#)

Network Identification configured automatically on installation. If you would wish to change the server name or the IIS port number, change the Server and Port in Network Identification.




**Figure 49 - Global Settings - Server Settings**

Another example of Network Identification information follows.

 **Select Domain**

Configure Domain:

---

 **Network Identification**

Server:

Port:


HTTP Mode:


Click the  Save button to apply the changes.

## Additional Domain Settings

Domain settings can only be modified by a user that is an administrator for the domain or parent domain. Domain setting are available from the “Domain Setting” web page


### Transmission and Retry Settings (Domain Settings)

Click the  Domain Settings link then followed by the

 Domain Settings

link to view the domain settings page.

Configure the number of delays and retries for the selected domain.



Transmission & Retry Settings	
Delay of Fax Retry (sec)	60
Delay of Raw Fax Retry (sec)	60
Delay of Email Retry (sec)	60
Delay of Http Retry (sec)	60
Delay of Ftp Retry (sec)	60
Delay of File Retry (sec)	60
Delay of Mobile Retry (sec)	60
Delay of Printer Retry (sec)	60
Max Attempt of Fax	3 ▼
Max Attempt of Raw Fax	3 ▼
Max Attempt of Email	3 ▼
Max Attempt of Http	3 ▼
Max Attempt of Ftp	3 ▼
Max Attempt of File	3 ▼
Max Attempt of Mobile	3 ▼
Max Attempt of Printer	3 ▼



**Figure 50 - Domain Settings - Domain Settings - Transmission and Retry Settings**

- Delay of Fax Retry - This will retry every fail faxes in X amount of time and value is in minute.
- Delay of Raw Retry - This will retry every fail raw faxes in X amount of time and value is in minute.
- Delay of Email Retry - This will retry every fail Email deliveries in X amount of time and value is in minute.
- Delay of Http Retry - This will retry every fail http post in X amount of time and value is in minute.
- Delay of FTP Retry - This will retry every fail FTP drops in X amount of time and value is in minute.
- Delay Of File Retry - This will retry every fail File drops in X amount of time and value is in minute.

- Delay Of Mobile Retry - This will retry every fail Mobile Calls in X amount of time and value is in minute.
- Delay Of Printer - This will retry every fail Print in X amount of time and value is in minute.
- Max Attempt of Fax - Maximum number of FAX attempts to try before failing.
- Max Attempt of Email - Maximum number of Email attempts to try before failing.
- Max Attempt Of Http - Maximum number of HTTP attempts to try before failing.
- Max Attempt of Ftp - Maximum number of FTP attempts to try before failing.
- Max Attempt of File - Maximum number of FILE attempts to try before failing.
- Max Attempt of Printer - Maximum number of Print attempts to try before failing.




## User Permissions (Domain Settings)

Click the  **Domain Settings** link then followed by the  **User Permissions** link to view the user permissions page.

Permissions set at the domain level for the entire domain. The system administrator can define domain level permissions that in many cases override user level permission set up by domain administrators. For example, the system administrator can specify that a particular domain is not allowed to send international faxes.


Even if the domain administrator specifies that the users can send international faxes, the setting will be overridden by the domain level setting.



**Figure 51 - Domain Settings - User Permissions**

## **Send Permissions**

Send permissions are related to sending a message.




**Figure 52 - Domain Settings - Send Permissions**

- Allow Sending - Allow domain to send any message.
- Allow Fax Sending - Allow domain to send fax.
- Allow International Fax - Allow domain to fax international.
- Allow Color Faxing - Allow domain to fax in color.
- Allow Email - Allow domain to send email.
- Allow HTTP Sending - Allow domain to send HTTP posts.
- Allow FTP Sending - Allow domain to upload FTP.

- Allow File Sending - Allow domain to upload File.
- Allow Printer Sending - Allow domain to print to printer.
- Allow Mobile Sending - Allow domain to dial to Mobile.

## Received Permissions

Received Permissions is related to message that received and permission to allow users to do.




Receive Permissions	
Allow forwarding	Yes
Allow fax forward	Yes
Allow raw fax forward	Yes
Allow email forward	Yes
Allow email attachments	Yes
Email attachment max size	Unlimited
Allow printing	Yes
Allow http forward	Yes
Allow ftp forward	Yes
Allow file forward	Yes
Allow mobile forward	No

**Figure 53 - Domain Settings - Receive Permissions**

- Allow Forwarding – Allow domain to forward message.
- Allows Fax Forwarding – Allow domain to forward fax message.
- Allows Raw Fax Forwarding – Allow domain to forward raw fax message.
- Allows Email Forwarding - Allow domain to forward email message.
- Email Attachment Max Size – Allow domain to set maximum attachment size from 100KB to 9MB and unlimited.
- Allow Printing - Allow domain to print
- Allow Http Forwarding - Allow domain to forward to http post
- Allow Ftp Forward – Allow domain to forward to FTP folder
- Allow File Forward – Allow domain to forward a message to folder
- Allow Mobile Forward – Allow domain to forward message to mobile



## Document Permissions



**Figure 54 - Domain Settings - Document Permissions**


- Allow Document Upload – Allow domain to upload and share document.
- Document Quota – Allow domain to upload documents with a maximum size from 100kb to 9mb and unlimited.

## Domain Setting – Domain Settings

Click the  link then followed by the  link to view the domain settings page.

## Email Delivery / Notification Identification

Control the identity of the various types of email sent by the FaxCore Engine.




**Figure 55 - Domain Settings – Domain Settings – Email Notification/Delivery Identity**

- Password Sender Email – Address that appears in the “From” field for password reminder emails.
- Notification Sender Email From – Address that appears in the “From” field for notification emails.
- Delivery Email From – Address that appears in the “From” field for delivery emails.

## Message Setting

Messages Setting is a function where admin are allow to set simple work flow which messages need to approved by a paticular user.



**Figure 56 - Domain Settings – Domain Settings – Message Settings**

- Approval User – Message which needed the user to approve.

- Maximum Tracking Key – Number of column to be shown on FaxCore site.

## Support Request Setting





Support Request Settings	
Support Company	FaxCore, Inc.
Support Address	Suite 207, 19590 E Main Street, Parker, CO 80138
Support Phone	+1 (720) 870-2900
Support Web Site	http://www.faxcore.com
Support Email From	support@faxcore.com
Support Request Email	support@faxcore.com

**Figure 57 - Domain Settings – Domain Settings – Support Request Settings**

- Support company - Name of the company handling customer support.
- Support Address – Support company address.
- Support Phone – Support phone.
- Support Web Site – Support Web sites
- Support Email From - Email Signature that appears in the field of emails sent from the support web page.
- Support Request Email – Email address to send support request.
- Support Request URL – URL to port support request.

## Notification Delivery Templates

Click the  **Domain Settings** link then followed by the  Domain Settings link to view the domain settings page.

Notification Delivery Templates		
Send Delivery	delivery	▼
Message send success	notifyMessageSendSuccess	▼
Message send error	notifyMessageSendFailed	▼
Message receive success	notifyMessageReceiveSuccess	▼
Message receive error	notifyMessageReceiveFailed	▼
Recipient receive success	notifyRecipientReceiveSuccess	▼
Recipient receive error	notifyRecipientReceiveFailed	▼
Message assign receive notification	notifyMessageAssignReceive	▼
Message forward receive notification	notifyMessageForwardReceive	▼
Send password notification	sendPassword	▼
Message print template	delivery	▼
Approval Request Notification	notifyMessageApprovalRequest	▼
Approved Reply Notification	notifyMessageApprovalApproved	▼
Rejected Reply Notification	notifyMessageApprovalNotApproved	▼

**Figure 58 - Domain Settings – Domain Settings –Notification Delivery Templates**

FaxCore provides message delivery and notifications to a variety of protocols including: email, http, and ftp. Each of these different protocols has a distinct set of properties that control processing and formatting of the delivered message. For example, email deliveries contain a subject, body, and importance, while ftp deliveries must specify an upload directory and file name for each file transferred.

Delivery Templates are just what their name implies: templates that control how the protocol specific properties of each delivery are set and/or formatted. Delivery Templates are created and owned by a Domain and have the following characteristics:

- Each template is owned by a single domain, and can be visible to child domains based on its “Visibility” setting.
- Each template contains configuration setting for every supported protocol.
- An unlimited number of templates can be created
- Templates can be assigned at the domain level and also at a user level, giving you precise control how delivery message appear. Only Domain Administrator can create and assign templates.

## User Permissions

This section configures the user level permissions and quotas for a selected domain.







Figure 59 - Domain Settings - User Permissions

### Select Domain



### User General Permissions






- Allow Auto-Login – Specifies if users are allowed to use the auto-login feature for FaxCore website.
- Allow User to assign messages – Specifies if users are allowed access to specify advanced delivery level notifications. Users are only allowed access to message level notifications unless advance notifications are allowed.
- Allow delete message permanently – Specifies if users are allowed to permanently delete a fax message from FaxCore.
- User privilege – Specifies minimum users privilege level to allow permanent deletion of fax messages.
- Enable Exchange Address Book Integration – Specifies exchange server address book integration

### Users Public Address Book

Permissions for editing Domain public address books.




**User Public Address Book Permissions**

Allow address book edit	Yes
Minimum required edit privilege	SUPER USER

- **Allow address book edit** – Indicates if users have the permissions to edit public (Domain) address book. If editing is allow, permission depends on the minimum required edit privilege setting.
- **Minimum required edit privilege** –Minimum user privilege level required to edit public domain address books.

### Personal Folder Permission and Notification Permission



**Personal Folder Permission**

Allow personal folder level	3
-----------------------------	---

**Notification Permissions**


Allow Notify When Message Receive Success	Yes
Allow Notify When Message Receive Fail	Yes
Allow Notify When Message Send Success	Yes
Allow Notify When Message Send Fail	Yes

- **Allow Personal Folder Level** – Allow users to create folder level and control the folder level.
- **Allow Notify When Message Receive Success** – Allows FaxCore to notify the users when receive success.
- **Allow Notify When Message Receive Fail** - Allows FaxCore to notify the users when receive Fails.



- **Allow Notify When Message Send Success** – Allows FaxCore to notify the users when send success.
- **Allow Notify When Message Send Fail** - Allows FaxCore to notify the users when send Fail

### Receive Permissions



**Receive Permissions**

Allow forwarding	Yes
Allow fax forward	Yes
Allow raw fax forward	Yes
Allow email forward	Yes
Allow email attachments	Yes
Email attachment max size	Unlimited
Allow printing	Yes
Allow http forward	Yes
Allow ftp forward	Yes
Allow file forward	Yes
Allow mobile forward	No

- **Allow Forwarding** – Allow users to forward any the message.
- **Allow Fax Forwarding** – Allow user to forward a fax message.
- **Allow Raw Fax Forwarding** – Allow user to forward a raw fax message.
- **Allow Email Attachment Max Size** – Define the maximum size of the email attachment.
- **Allow Printing** – Allow users to print to a printer.
- **Allow HTTP Forward** – Allow users to forward to HTTP sites.
- **Allow FTP Forward** – Allow users to forward to FTP sites
- **Allow File forward** – Allow users to forward as file.
- **Allow Mobile Forward** – Allow users to forward to mobile.

## Send Permissions

Permissions set at the domain level for the entire domain. The system administrator can define domain level permissions that in many cases override user level permission set up by domain administrators. For example, the system administrator can specify that a particular domain is not allowed to send international faxes. Even if the domain administrator specifies that the users can send international faxes, the setting will be overridden by the domain level setting.




Send Permissions	
Allow sending	Yes
Allow fax sending	Yes
Allow international fax	Yes
Allow color faxing	No
Allow raw fax sending	Yes
Allow email sending	Yes
Allow http sending	Yes
Allow ftp sending	Yes
Allow file sending	Yes
Allow printer sending	Yes
Allow mobile sending	No

- **Allow Sending** – Allow users to send any message.
- **Allow Fax Sending** – Allow users to send a fax message.
- **Allow International Fax** – Allow Users to send international fax
- **Allow Raw Fax Sending** – Allow Users to send raw fax.
- **Allow Email Sending** – Allow Users to send email.
- **Allow HTTP Sending**- Allow users to send to HTTP.
- **Allow FTP Sending** – Allow users to send to FTP.
- **Allow File Sending** – Allow Users to send as File
- **Allow Printer Sending** – Allow users to send to printer.
- **Allow Mobile Sending** – Allow users to send to mobile.

## Document Permissions

Document permissions related to uploading documents.




**Document Permissions**

Allow Document Upload	Yes
Document Quota	5 MB

- **Allows Document Upload** - Specifies if the users are allowed to upload document into the document store.
- **Document Quota** - Maximum amount of total space that is allowed for uploaded documents in the domain.

## Fax Settings

Default Telco dialing setting used in the send page and for dialing permissions



**FAXCORE ADMIN PANEL** Log Off

Domain Settings | Save | Apply All | Help

**Select Domain**  
Configure Domain: SYSTEM


**Dialing Rules**

Country Code	1
Area Code	
Dial Prefix	
Dial Prefix Rule	Use agent configuration only
Dial Suffix	
Dial Suffix Rule	Use agent configuration only

**Fax Send Setting**

Local CSID	1-720-870-4141
Local Caller ID	1-720-870-4141
Local Number	1-720-870-4141
Default Fax Format	Fax

## Dialing Rules




**Dialing Rules**

Country Code	1
Area Code	
Dial Prefix	
Dial Prefix Rule	Use agent configuration only
Dial Suffix	
Dial Suffix Rule	Use agent configuration only



## **Fax Send Setting**

Fax protocol setting and properties used in fax headers and footers.




Fax Send Setting	
Local CSID	1-720-870-4141
Local Caller ID	1-720-870-4141
Local Number	1-720-870-4141
Default Fax Format	Fax
Email Notification Format	with attachment
Email Attachment Max Size	1 MB
Resolution	Fine (204x196)

- Local CSID – Default CSID of the company / domain.
- Local Caller ID – Default local caller id.
- Local Number – default local number.
- Default Fax Format – Default format for fax number parsing. Fax or raw fax
- Email Notification Format – Defaults email notification with or without fax attachment
- Email Attachment Max Size – Defaults the maximum attachment size limit to be enclosed with notification email.
- Resolution – Determines the resolution of the faxes to be sent.

## Fax Receive Setting and Default Cover Page

Permission related to receiving faxes.



The screenshot shows a web-based configuration interface for FaxCore. It is divided into two main sections. The first section, titled 'Fax Receive Setting' with a fax machine icon, contains four settings: 'Allow Fax Received Partially' set to 'Yes', 'Forward Email Notification Format' set to 'with attachment', 'Forward Email Attachment Max Size' set to '1 MB', and 'Un-assigned Message User' set to 'SYS-UNROUTED(SYSTEM)'. The second section, titled 'Default Send Attachment(Cover Page)' with a fax machine icon, contains one setting: 'Cover Page' set to 'Default CoverPage'.

- **Allow fax received partially** – Enable fax to receive even if it is partially failed.
- **Forward email notification format** – Allow email notification for received faxes.
- **Forward email attachment max size** – maximum size to allow for email attachment.
- **Unassigned message user** – Choose users to assign unassigned faxes.
- **Cover Page** – Choose a default cover page to send.


## Tracking Configuration

FaxCore supports an unlimited number of properties that can be stored per message. Every property in FaxCore has a corresponding property definition that contains the following attributes.

FaxCore allows configuration of the tracking key property as it appears on fax send user interface, including control of its label, allow values, validation expression, data type, minimum and maximum values, etc.








- Domain – Define domain.
- Display Label – Label as it appears on the send fax interface.
- Date Format – There expected data format of the property.
- Value Length (Min) – Minimum accepted character length.
- Value Length (Max) – Maximum accepted character length.
- Length Set (Min) – Minimum property data length.
- Length Set (Max) – Maximum property data length.
- Is Required – Indicate if the tracking key value is required when entered through the FaxCore send interface
- Activate – Indicate to enable or disable
- Validating Dictionary – custom defined dictionary used to validate the input.





**Track Dictionary - Windows Internet Explorer provided by Yahoo!**

http://co.faxcore.com/admin/DmnSetting/TrackDictionary.aspx

Save Refresh Help

**Track Details**

Name:

Domain: SYSTEM

Visibility: Private

Active: Yes

**Dictionary Entries**

Entry Name:

Entry Type: Normal

Entry Value:

Add Cancel

Edit	Remove Name	Value	Auto Number	Increment By
No entries added				


Done, but with errors on page. Internet 100%

- **Name** – Name of the template. The template name must be unique within the owning domain.
- **Domain** – Domain that owns the template
- **Visibility** – Defines the visibility of the template to its sub domains. Setting to public allows the template to be used by sub domains.
- **Active** – activating the template
- **Entry Name** – Name for display in user interface.
- **Entry Type** – Type of the value
- **Entry Value** – The value that is stored when the entry is selected.



## Domain Info

The domain info page provides summary information of the domain and allow administrator to create, delete and rename domains within FaxCore.



**SYSTEM**

- TEST DOMAIN
  - FaxScan
  - FaxCore
  - TMI
  - Demo Accounts
  - 5280
  - Telovations
  - PEI
  - Sharp
  - One Touch
  - Emporiki Credicom

Save Refresh Help

### Domain Information

Domain name: SYSTEM

Description: System Domain

Date Created: 12/31/2007 1:41:31 PM

Active: Yes

### User Summary

Total Users: 28

Synchronized Users: 17



Non-synchronized Users: 11

### User Summary Including Child Domains

Total Users: 117

Synchronized Users: 47

Non-synchronized Users: 70



## Users

Displays the list of users in the domain, and provides the main interfaces for creating and editing users. See Creating and Maintaining Users for detailed information and instructions on creating and maintaining users.

<input type="checkbox"/> User Name	Domain Name	Status	Multi...Ext...Role		
<input type="checkbox"/> 54F05022-0440-4722-8	SYSTEM	Active	No	Yes	STANDARD USER
<input type="checkbox"/> ADMIN	SYSTEM	Active	Yes	No	SYSTEM ADMIN
<input type="checkbox"/> ADMINISTRATOR	SYSTEM	Active	No	Yes	STANDARD USER
<input type="checkbox"/> APPADMIN	SYSTEM	Active	No	Yes	STANDARD USER
<input type="checkbox"/> ASPNET	SYSTEM	Active	No	Yes	STANDARD USER
<input type="checkbox"/> BESADMIN	SYSTEM	Active	No	Yes	STANDARD USER
<input type="checkbox"/> DBILLS	SYSTEM	Active	No	Yes	DOMAIN ADMIN
<input type="checkbox"/> DLOOMIS	SYSTEM	Active	No	No	STANDARD USER
<input type="checkbox"/> EM-CODES	SYSTEM	Active	Yes	No	DOMAIN ADMIN

Click the  **New** button to begin adding a user.



User Management - Windows Internet Explorer provided by Yahoo!

http://co.faxcore.com/admin/DmnMgmt/UserForm.aspx?domain=0

Save Help

### Select Domain

Configure Domain: SYSTEM

### User Info

**User Name**

**User Password**

User Role: SUPER USER

Authentication Type: Internal

Is Active: Yes

Display Name

First Name

Middle Name

Last Name

Prefer Address Type: EMAIL

### Addresses


Add Address

Edit	Remo...	NOR	NOS	Prima...	Type	Address
No address(es) added						

Done Internet 100%

## Groups

New
Delete
Move
Refresh
Help



### Select Domain

Configure Domain
SYSTEM
Number of items to display
15

<input type="checkbox"/> Acti...	Group Name	Group Description
There are no groups currently in the selected domain		

Change page: < 1 > | Displaying page 1 of 1, items 1 to 0 of 0.

Click the  button to begin adding a group.





Domain - Address Book - Windows Internet Explorer provided by Yahoo!

http://co.faxcore.com/Common/Dialog/AddressBookEdit.aspx?domain=0

Save Test Connection Read Data Reset Help

### Select Domain

Configure Domain: SYSTEM

### Address Book Editor

Address Book Name:

Description:

Visibility: Private

Address Book Type: External

Connection Type: OleDb Connection

Connection String:

Query Expression:


\* the variables @username can be used in query expressions to limit the query.  
Eg: select \* from tcontacts where xName like @username

@username:

\* @username is used for read data from external address book.  
Changes on this field will not be saved.

Done Internet 100%

## Delivery Templates





**Select Domain**

Configure Domain:  Number of items to display:

<input type="checkbox"/> Name	Visibility	Date Created
<input type="checkbox"/> deb received fax confirmation	Private	7/8/2008 7:22:29 AM
<input type="checkbox"/> delivery	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageApprovalApproved	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageApprovalNotApproved	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageApprovalRequest	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageAssignReceive	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageForwardReceive	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageReceiveFailed	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageReceiveSuccess	Public	12/31/2007 1:39:02 PM

Change page: < 1 2 > | Displaying page 1 of 2, items 1 to 15 of 17.

Click the  button to add a new delivery template.



**Delivery Template - Windows Internet Explorer provided by Yahoo!**

http://co.faxcore.com/admin/DmnMgmt/DeliveryTemplateForm.aspx?ID=0&domain=0&isNew=1

Save As New Save

**General Information**

Name:  Domain:

Description:  Visibility:

**Delivery Method:** Fax | Email | HTTP | FTP | File | Print

**Header**

Subject:

Notes:

**Cover Page**

Cover Page:

Include Fax As Attachment:

Priority:

Send Using User Profile:

Fax Address:

Send as Raw:







To delete a template....


The screenshot shows the FaxCore Admin Panel interface. At the top, there are buttons for 'New', 'Delete', 'Move', 'Refresh', and 'Help'. Below these is a 'Select' button and a 'Delete' button. A 'Configure Domain' dropdown menu is set to 'SYSTEM'. To the right, 'Number of items to display' is set to '15'. Below this is a table with three columns: 'Name', 'Visibility', and 'Date Created'.

Name	Visibility	Date Created
<input checked="" type="checkbox"/> deb received fax confirmation	Private	7/8/2008 7:22:29 AM
<input type="checkbox"/> delivery	Public	12/31/2007 1:39:02 PM
<input type="checkbox"/> notifyMessageApprovalApproved	Public	12/31/2007 1:39:02 PM

## Network Setting

### Message Queue Monitor

FaxCore Message Queue displays real time status to be process in the task. The dropdown menu lets you select which process that you wish to see either in Fax, Email, Ftp, HTTP and Printer. The complete lists of actions are discussed below.



Message Type: Fax Refresh

**Server Queue Monitor**


Transmit ID	Date Created	Date Scheduled	Priority	Is Ready?	Processing Date	FaxAgent	Server	Module	Channel
20180000000...	10/11/2007 11:47:35 AM	10/11/2007 11:46:24 AM	10	1		-1			-1

- **Transmit ID** – Internal FaxCore ID for the object.
- **Date Created** – Date and time the object was placed on the queue
- **Date Scheduled** – Date and time the object to be schedule to do the process.
- **Priority** – Current priority of the object.
- **Is Ready?** – Current state if is ready to send for process.
- **Processing Date** – Date to do the process.
- **Fax Agent** – Fax Agent that is responsible to do the process.
- **Server** – Server that is responsible to do the process.
- **Module** – Module that FaxCore assign to process the fax.
- **Channel** – Channel to process the fax queue.



- **Import File** – The location of the data file in the data file is specified using a control file.
- **Header Format** – Format for the CSV header.
- **Has header** – Display the CSV that has header.
- **Format** – Identifies the data file to import. The data file format must match the specified control file.
- **Table Name** – Name for the table.

## Default Settings




- **Address Book** – Name of the new address book. The template name must be unique within the owning domain.
- **Contact Group** – Name of the new group.
- **Contact Groups Description** – Distribution group description if the contact group identified above is newly created during the import.
- **Contact Group View Only** – Allow only group to view this contacts.
- **File Attachment Format** - Default file attachment format for addresses.
- **Prefer Address Type** – Indicates if the primary delivery addresses type for the contact.
- **Visibility** – Defines the visibility of the template to its sub domain. Setting to public allows the template to be used by sub domains.

## Import Contacts from CSV Schema




The following table shows the list of data fields that appears in the pre-configured control file.






## Product Information

 <b>Product Information</b> FaxCore Web Client Version: 5.2.0.63 FaxCore FXC Version: 5.2.8.37267 FaxCore FXC BL Version: 5.2.10.37254 FaxCore DB Access Version: 5.2.4.35468 FaxCore IMG/BC Version: 5.2.2.6793  DB Version: FC07.008.10.10.2013	<ul style="list-style-type: none"> <li>• FaxCore Web Client Version - Indicates the current web build version.</li> <li>• FaxCore FXC Version – Indicates the current FXC component version.</li> <li>• FaxCore FXC BL Version – Indicates the current FXC BL component version.</li> <li>• FaxCore DB Access Version – Indicates the DB Access version.</li> <li>• FaxCore IMG/BC Version – Indicates the IMG/BC component version.</li> <li>• DB Version – Indicates the database schema version.</li> </ul>
---	--

## Error Logging

Error logging is a component that lets administrators view, manage and gather information about the hardware and the software problem. Click  Refresh to see the latest information if there is any and to delete simply check the check-box and click the  Delete button. To clear all logs, just click the  Clear Log button.

 Refresh  Delete  Clear Log					Number of items to display 15	
<input type="checkbox"/>	Error Message	Error Details	Error Group	Error Le		
<input type="checkbox"/>	<a href="#">View</a> Invalid attempt to read when no data is present.	System.Data.DataRowView	FaxAgent WS	Error		
<input type="checkbox"/>	<a href="#">View</a> Object cannot be cast from DBNull to other types.	System.Data.DataRowView	UpdateOBTransmit	Error		
<input type="checkbox"/>	<a href="#">View</a> Object cannot be cast from DBNull to other types.	System.Data.DataRowView	UpdateOBTransmit	Error		
<input type="checkbox"/>	<a href="#">View</a> Object cannot be cast from DBNull to other types.	System.Data.DataRowView	UpdateOBTransmit	Error		
<input type="checkbox"/>	<a href="#">View</a> Invalid attempt to read when no data is present.	System.Data.DataRowView	FaxAgent WS	Error		

## Token Reference

Tokens are substitution parameters that are used to incorporate dynamic content into cover pages, templates, and notifications generated by FaxCore. Tokens play an important role in virtually all inbound and outbound messages processed by FaxCore.



## Configuration Tokens

Configuration tokens derive values from user and domain configuration options. Configuration tokens begin with the prefix: CONFIG. In all tokens below, the data for the tokens are resolved from the values (overridden or inherited) in the configuration settings screens (Eg: general settings, receive settings, domain configuration settings).

Configuration Tokens	
CONFIG.COMPANY_ADDRESS_CITY	Domain Company Address City
CONFIG.COMPANY_ADDRESS_COUNTRY	Domain Company Address Country
CONFIG.COMPANY_ADDRESS_POSTAL	Domain Company Address Postal
CONFIG.COMPANY_ADDRESS_STATE	Domain Company Address State
CONFIG.COMPANY_ADDRESS_STREET1	Domain Company Address Street 1
CONFIG.COMPANY_ADDRESS_STREET2	Domain Company Address Street 2
CONFIG.COMPANY_ADDRESS_STREET3	Domain Company Address Street 3
CONFIG.COMPANY_NAME	Domain Company Name
CONFIG.FAX.DIAL_PREFIX	Domain Fax Dial Prefix
CONFIG.FAX.DIAL_SUFFIX	Domain Fax Dial Suffix
CONFIG.FAX.LOCAL_CALLER_ID	Domain Fax Local Caller ID
CONFIG.FAX.LOCAL_CSID	Domain Fax Local CSID
CONFIG.FAX.LOCAL_NUMBER	Domain Fax Local Number
CONFIG.FAX.XMIT_FOOTER	Domain Fax Transmission Footer
CONFIG.FAX.XMIT_HEADER	Domain Fax Transmission Header
CONFIG.GENERAL.DELIVERY_FROM	General Delivery From
CONFIG.GENERAL.FXC_HTTP_MODE	General FXC HTTP
CONFIG.GENERAL.FXC_PORT	General FXC Port
CONFIG.GENERAL.FXC_SERVER	General FXC Server



Configuration Tokens	
CONFIG.GENERAL.NOTIFICATION_FROM	General Notification From
CONFIG.GENERAL.PASSWORD_SENDER_FROM	General Password Sender From
CONFIG.GENERAL.URL_MESSAGE_VIEWER	General URL Message Viewer
CONFIG.TELCO.DIAL_RULES_AREA_CODE	Domain Area Code
CONFIG.TELCO.DIAL_RULES_COUNTRY_CODE	Domain Country Code

## Message Token

Message Tokens derive values from properties of a sent or received message (fax). For example, # of pages, remove fax number, transmit time, etc. Message tokens begin with the prefix: *MESSAGE*.

In the tables below, **Multi** indicates if the token is multi-valued, and **Params** indicate the parameters that must appear in the token specification (separated by semi-colons).

Message Tokens	
MESSAGE.BILLING_CODE	Message Billing Code
MESSAGE.DATE	Message Create Date
MESSAGE.DATE_TIME	Message Create Date Time
MESSAGE.FROM_COMPANY_NAME	Message Sender Company Name
MESSAGE.FROM_NAME	Message Sender Name
MESSAGE.ID	Message ID
MESSAGE.IS_OUTBOUND	Message Inbound or Outbound
MESSAGE.IS_SUCCESS	Message Status
MESSAGE.NOTE	Message Note
MESSAGE.NUMBER	Message Number
MESSAGE.OWNER_DOMAIN_ID	Message Owner Domain ID
MESSAGE.OWNER_DOMAIN_NAME	Message Owner Domain Name
MESSAGE.OWNER_USER_ID	Message Owner User ID

Message Tokens	
MESSAGE.OWNER_USERNAME	Message Owner UserName
MESSAGE.REFERENCE_NUMBER	Message Reference Number
MESSAGE.SENDER_COMPANY_NAME	Message Sender Company Name
MESSAGE.SENDER_NAME	Message Sender Name
MESSAGE.SUBJECT	Message Subject
MESSAGE.TIME	Message Create Time
MESSAGE.TRACKING_KEY	Message Tracking Key
MESSAGE.TRANSACTION_COUNT	Message Transaction(s) Count
MESSAGE.TRANSACTION_COUNT_CANCELLED	Message Transaction(s) Cancelled
MESSAGE.TRANSACTION_COUNT_COMPLETED	Message Transaction(s) Completed
MESSAGE.TRANSACTION_COUNT_FAILED	Message Transaction(s) Failed
MESSAGE.TRANSACTION_COUNT_IN_PROCESS	Message Transaction(s) In Process
MESSAGE.XSACT.ADDRESS_FORMAT_TYPE	Message Transaction Address Format Type
MESSAGE.XSACT.ATTEMPT_COUNT	Message Transmission Attempt Count
MESSAGE.XSACT.BARCODE	Message Transaction Barcode
MESSAGE.XSACT.COMPLETE_DATE	Message Transaction Complete Date
MESSAGE.XSACT.DISPLAY_ADDRESS	Message Transaction Display Address
MESSAGE.XSACT.IS_SUCCESS	Message Transaction Successful Or Not
MESSAGE.XSACT.NUMBER_PAGES_SENT	Message Transaction Total Sent Page

Message Tokens	
MESSAGE.XSACT.RECIPIENT_COMPANY_NAME	Message Transaction Recipient Company Name
MESSAGE.XSACT.RECIPIENT_NAME	Message Transaction Recipient Name
MESSAGE.XSACT.TRANSACTION_ID	Message Transaction ID
MESSAGE.XSACT.XMIT.CALLER_ID	Message Transmission Caller ID
MESSAGE.XSACT.XMIT.PORT_NO	Message Transmission Port No
MESSAGE.XSACT.XMIT.REMOTE_CSID	Message Transmission Remote CSID
MESSAGE.XSACT.XMIT.ROUTE_DIGITS	Message Transmission Routing Digits
MESSAGE.XSACT.XMIT.SERVER_NAME	Message Transmission Server Name
MESSAGE.XSACT.XMIT_CALL_TIME	Message Transmission Total Time
MESSAGE.XSACT.XMIT_ERROR_ID	Message Transmission Error ID
MESSAGE.XSACT.XMIT_ERROR_INFO	Message Transmission Error Info
MESSAGE.XSACT.XMIT_TIME	Message Transmission Time
MESSAGE.XSACT_PAGE_COUNT	Message Transaction Page Count

## User Token

User Profile Tokens derive values from the user profile (See User Profile Configuration) including username, display name, last and first name, etc. User profile tokens begin with the prefix: *USER*. **Note:** in the table below, **Multi** indicates if the token is multi-valued, and **Params** indicate the parameters that must appear in the token specification (separated by semi-colons).

User Token	
USER.COMPANY_NAME	User Company Name
USER.DISPLAY_NAME	User Display Name
USER.DOMAIN_ID	Domain ID
USER.DOMAIN_NAME	User Domain Name
USER.FIRST_NAME	User First Name
USER.LAST_NAME	User Last Name
USER.MIDDLE_NAME	User Middle Name
USER.PASSWORD	User Password
USER.PRIMARY.MOBILE_PHONE	User Primary Mobile Phone
USER.PRIMARY_EMAIL	User Primary Email
USER.PRIMARY_FAX	User Primary Fax
USER.PRIMARY_PHONE	User Primary Phone
USER.ROLE_ID	User Role ID
USER.USERID	User ID
USER.USERNAME	User UserName

## Table of Figures

Figure 1 - FaxCore Login Screen.....	5
Figure 2 - ADMIN Panel .....	5
Figure 3 – Fax Agent Management.....	6
Figure 4 – Fax Agent Management - Configuration.....	8
Figure 5 – Fax Agent Management - Ports .....	9
Figure 6 – Fax Agent Management - Ports - Edit Port Configuration .....	10
Figure 7Ports - Edit Port Configuration - Greeting Type .....	10
Figure 8Ports - Edit Port Configuration - Header Style.....	10
Figure 9 – Fax Agent Management -Dialing Rules .....	11
Figure 10 – Fax Agent Management -Custom Dialing Rules.....	11
Figure 11 – Fax Agent Management -Port Groups.....	12
Figure 12 – Global Setting -Outbound Routing Rules.....	13
Figure 13 – Global Setting -Outbound Routing Rule .....	14
Figure 14 - Domain Settings - Company Information .....	16
Figure 15 - Domain Settings - Regional and Language Settings .....	17
Figure 16 - Domain Settings - Attachment Settings .....	17
Figure 17 - Domain Management - Users.....	18
Figure 18 - Domain Management - User Information .....	19
Figure 19 - Domain Management - User's Address.....	20
Figure 20 - Domain Management - User's Addresses.....	20
Figure 21 - Domain Settings - Directory Sync – Directory Connection.....	21
Figure 22 - Domain Settings – Directory Sync - Search Filter Settings .....	22
Figure 23 - Domain Settings – Directory Sync - Processing Rules - General .....	22
Figure 24 - Domain Settings – Directory Sync - Processing Rules – User ID .....	23
Figure 25 - Domain Settings – Directory Sync - Processing Rules – New User Handling .....	23
Figure 26 - Domain Settings – Directory Sync - Processing Rules – Existing User Handling.....	23
Figure 27 - Domain Settings – Directory Sync - Processing Rules – Inbound Route Handling.....	24
Figure 28 - Domain Settings – Directory Sync - Processing Rules – Deleted User/Domain Handling.....	24
Figure 29 - Domain Settings – Directory Sync - Processing Rules - General .....	25
Figure 30 - Utilities - Import Users.....	25
Figure 31 - Global Settings - Inbound Routing.....	28
Figure 32 - Global Settings - Inbound Routing Rule .....	28
Figure 33 - Domain Settings - User Permissions.....	30
Figure 34 - Global Settings – Server Settings.....	31
Figure 35 - Domain Settings – SMTP Relay Settings.....	32
Figure 36 - Internet Information Services (IIS) Manager .....	33
Figure 37 - Internet Information Services (IIS) Manager – Access Properties.....	33
Figure 38 - Internet Information Services (IIS) Manager –Properties.....	34
Figure 39 - Default SMTP Virtual Server - Domain - New.....	34
Figure 40 - New SMTP Domain Wizard Dialog Box.....	35
Figure 41 - New SMTP Domain Wizard Dialog Box.....	35
Figure 42 - MS Exchange System Manager .....	36
Figure 43 - MS Exchange System Manager - Properties – General .....	37
Figure 44 - MS Exchange System Manager – Other Address Space Properties.....	37
Figure 45 - Global Settings - Printer Settings.....	38
Figure 46 - Global Settings - Printer Settings - Network Printer .....	39
Figure 47 - Global Settings - Email Integration.....	42
Figure 48 - Global Settings - Email Integration Setting .....	43
Figure 49 - Global Settings - Server Settings .....	44
Figure 50 - Domain Settings - Domain Settings - Transmission and Retry Settings.....	45
Figure 51 - Domain Settings - User Permissions.....	47

Figure 52 - Domain Settings - Send Permissions.....	47
Figure 53 - Domain Settings - Receive Permissions.....	48
Figure 54 - Domain Settings - Document Permissions .....	49
Figure 55 - Domain Settings – Domain Settings – Email Notification/Delivery Identity .....	49
Figure 56 - Domain Settings – Domain Settings – Message Settings.....	49
Figure 57 - Domain Settings – Domain Settings – Support Request Settings .....	50
Figure 58 - Domain Settings – Domain Settings –Notification Delivery Templates.....	51
Figure 59 - Domain Settings - User Permissions.....	52